

Doc. Title.: XMM FOP
Doc. Ref.: XMM-MOC-PL-0022-SMD
Date: May 99

Issue : x
Revision: x

Procedure. Ref.: SVT_OPM_5010 (1,1) BASIC MODE TEST

Procedure Title: Basic Mode Test
Last Date Modified: 21/04/99 16:47:46
Author: Kate Adamson

Purpose of Procedure:

This procedure executes the Basic Mode Test. Command reception of OM is tested in the basic mode prior to loading the main application software.

This procedure is foreseen to be used during SVT.

Initial State: OM ON in INITIAL Mode

Final State: OM ON in INITIAL Mode

Step	Time	Activity/Remarks	Command	TM Verification
1		CHECK TEST COMMAND Send valid OM Test command. Confirm Successful Command Acceptance packet is received. Packet 91100 (PK Dump 3100 OM3) Confirm TC Packet Count is incremented.	<u>H0001</u> OM TEST COMMAND	<u>AND: H100</u> H5385 "TC PACKET COUNT" = 1
2		END OF PROCEDURE		