

Doc. Title.: XMM FOP
Doc. Ref.: XMM-MOC-PL-0022-SMD
Date: May 99

Issue : x
Revision: x

Procedure. Ref.: SVT_OPM_5102 (1,1) CHANGE TO SCIENCE MODE

Procedure Title: Change to SCIENCE Mode
Last Date Modified: 27/04/99 15:59:53
Author: Kate Adamson

Purpose of Procedure:

This procedure executes the mode change to SCIENCEMode.

This procedure is foreseen to be used during the OM SVT.

Initial State: OM ON in IDLE

Final State: OM ON and SCIENCE

Step	Time	Activity/Remarks	Command	TM Verification
1		VERIFY STATE OF OM		<u>AND: H100</u> H5395 "OM STATE" = IDLE H5405 "ICU STATE" = OPERATIONAL H5450 "DPU STATE" = DPUOS
2		CHANGE TO ICU MODE 3 - SCIENCE	<u>H9003</u> GOTO SCIENCE	
3		Wait up to 20 seconds. Check TM status		<u>AND: H100</u> H5395 "OM STATE" = SCIENCE H5405 "ICU STATE" = OPERATIONAL H5450 "DPU STATE" = DPUOS
4		END OF PROCEDURE		